MOTOR OPERATOR-MODEL FSM-25

08330/ATL Buyline 0371

SPECIFICATIONS

PART 1 GENERAL

1.01 Section includes

- A. Type: The motor operator will be Atlas Door™ Model FSM-25 as manufactured by Clopay Building Products, Inc.
- B. Mounting: To be vertical front of hood.

1.02 Related Work

- Electrical wires, wiring, disconnect switches, and conduit are in the scope of work of other sections or trades.
- B. Submit manufacturer's product data and installation instructions for each type of coiling door, Include both published data and any specific data prepared for this project.

1.03 Single-Source Responsibility

A. Provide doors, guides, motors, and accessories from one manufacturer for each type of door. Provide secondary components from source acceptable to manufacturer of primary components.

PART 2 PRODUCT

2.01 Operator

- A. Meter: Provide high torque, intermittentduty, squirrel-cage induction electric motor, ODP Motor 1PH, TENV motor 3PH. Permanent split capacitor motor for single phase applications. Operator is limited to 12 cycles per hour.
- Reduction: To be parallel shaft gearbox with aluminum die cast housing. Precisionmachined gearing, hardened for maximum load capability. Permanently lubricated.
- C. Drive: Product shaft to be driven by 41 series roller chain to provide travel of 6" (152.4 mm) to 12" (304.8 mm) per second.
- D. Brake: To be electrically activated magnetic disc type brake.
- E. Electrical Enclosure: All electrical components shall be in a NEMA 1 enclosure and pre-wired to terminal block.

- F. Reversing Contractor: Heavy-duty across the line reversing type with mechanical interlock, size "00," or equivalant.
- G. Limit Switches: To be positive direct drive screw type limit switch, enclosed in electrical control box, easily accessible for precision setting. Limit switches will retain settings during mechanical governed closure.
- H. Listing: UL 325.

2.02 Operation

- A. Automatic Powered Closing with Fire Power Operation: If the door is in the open position and an alarm condition occurs, the door will automatically close under motor operation. In the event the door should hit an obstruction while closing, it will reverse and return to the full open position, and then begin closing again. If the obstruction is not removed, the door will cycle approximately three times, finally closing and stopping at the lowest possible position. If after the door has finished the cycling mode and the obstruction is removed the door will proceed to the floor. If the door is reopened and the alarm condition is still present, then the door will immediately close to the lowest possible position.
- NOTE: Electronic Sensor Edge option is required with Fire Power.
- B. Automatic Closing: If the door is in the open position and a loss of power occurs, the door will automatically close by mechanical governed closure. No manual reset is required. Once power is restored, resetting the door is performed by pressing the open button. Closure will be governed between 6 to 24 inches per record.
- C. Fuse Link Release: If the door is in the open position and the fuse link melts, the door will automatically close by mechanical governed closure. Once the fuse link is replaced, resetting the door is performed by pressing the open button. (The door cannot be electrically operated until the fuse link is replaced.) Closure will be governed between 6 to 24 inches per second.

- D. Alarm Veltage: Type and voltage must be specified. Available in 12 VDC, 24 VDC, 24 VAC, and 115 VAC. Alarm can be maintained or all-safe capability, maintained voltages are recommended.
- E. Control Circuit: Shall be reduced to 24 VAC. Pre-wired for safety edge to reverse fuse link release, test key switch and three-buttonstation.
- F. Control Stations: To be one NEMA 1 surface mount three-button-station with open, close and stop functions. Momentary contact to open, close and stop.
- G. FIRESET** 2 Unique Controls: Includes NEMA 1 surface mount test key switch and fuse link release assembly.
- H. Overload Protection: Auto-resetting overload protection.

PART 3 EXECUTION

3.01 Installation

A. Installation: To be by an Atlas Door authorized representative in accordance with Atlas Door standards and instructions.

Note to Specifiers...Please see end of this section for frequently specified Optional Features.

AMPERAGE & HORSEPOWER DATA

MAX. Soure Area Motor Model	Shutter	Fire Door.	HP	Voltage	Phase	Апр	
FSM-25	120	100	Y ₂	115	1.	2.8	
	sq.ft.	sq.ft.		208	1	1.5	
				230	1	1.4	
				208	3	1.0	
				230	3	0.9	

*The actual maximum square footage will depend on the type of endlocks, bottom bar, gauge and the height to width selected.


**460 VAC motors require a 115 or 230 VAC single phase source for brake power.


MOTOR OPERATOR-MODEL FSM-25


08330/ATL Buyline 0371

• 1/4 H.P.

Used on: Fire Doors - "F" Series Labeled Counter Shutters - "L" Series







atlas door

Page CO-21